

Here is a partial list of radioactive contaminants inside a used steam generator from one of the Bruce reactors. The **amount of radioactivity** is expressed in becquerels per cubic metre; one becquerel corresponds to one radioactive disintegration every second. (Source: OPG) http://www.nwmo.ca/uploads_managed/MediaFiles/539_ReferenceLowandIntermediateWasteInventoryfortheDGR.pdf (p. 50)

<i>For Scientists / Engineers</i>			<i>For Citizens / Decision Makers</i>		
Symbol	Half-Life	Amount	Name	Half-Life	Amount
	(y)	(Bq/m ³)		(years)	(becquerels per cubic metre)
Ag-108	1.3E+02	2.3E+02	Silver-108	130 y	230
Am-241	4.3E+02	5.9E+07	Americium-241	430 y	59 000 000
Am-243	7.4E+03	3.8E+04	Americium-243	7 400 y	38 000
C-14	5.7E+03	7.6E+07	Carbon-14	5 700 y	76 000 000
Cl-36	3.0E+05	1.4E+04	Chlorine-36	300 000 y	14 000
Cm-244	1.8E+01	1.4E+07	Curium-244	18 y	14 000 000
Co-60	5.3E+00	1.2E+09	Cobalt-60	5.3 y	1 200 000 000
Cs-134	2.1E+00	1.9E+06	Cesium-134	2.1 y	1 900 000
Cs-135	2.3E+06	2.2E+01	Cesium-135	2 300 000 y	22
Cs-137	3.0E+01	2.2E+07	Cesium-137	30 y	22 000 000
Eu-152	1.3E+01	1.8E+06	Europium-152	13 y	1 800 000
Eu-154	8.8E+00	1.6E+07	Europium-154	8.8 y	16 000 000
Eu-155	5.0E+00	3.0E+07	Europium-155	5 y	30 000 000
Fe-55	2.7E+00	5.8E+09	Iron-55	2.7 y	5 800 000 000
I-129	1.6E+07	6.3E+00	Iodine-129	16 000 000 y	6.3
Nb-94	2.0E+04	2.9E+05	Niobium-94	20 000 y	290 000
Ni-59	7.5E+04	2.0E+05	Nickel-59	75 000 y	200 000
Ni-63	9.6E+01	2.9E+07	Nickel-63	96 y	29 000 000
Np-237	2.1E+06	1.8E+03	Neptunium-237	2 100 000 y	1 800
Pu-238	8.8E+01	1.0E+07	Plutonium-238	88 y	10 000 000
Pu-239	2.4E+04	1.2E+07	Plutonium-239	24 000 y	12 000 000
Pu-240	6.5E+03	1.7E+07	Plutonium-240	6 500 y	17 000 000
Pu-241	1.4E+01	5.5E+08	Plutonium-241	14 y	550 000 000
Pu-242	3.8E+05	1.7E+04	Plutonium-242	380 000 y	17 000
Ru-106	1.0E+00	8.4E+08	Ruthenium-106	1 y	840 000 000
Sb-125	2.8E+00	2.1E+07	Antimony-125	2.8 y	21 000 000
Se-79	1.1E+06	7.6E+01	Selenium-79	1 100 000 y	76
Sm-151	1.9E+01	7.6E+01	Samarium-151	19 y	76
Sn-126	2.1E+05	1.2E+02	Tin-126	210 000 y	120
Sr-90	2.9E+01	1.8E+07	Strontium-90	29 y	18 000 000
Tc-99	2.1E+05	2.8E+03	Technetium-99	210 000 y	2 800
U-234	2.5E+05	1.9E+04	Uranium-234	250 000 y	19 000
U-235	7.0E+08	3.2E+02	Uranium-235	700 000 000 y	320
U-236	2.3E+07	3.6E+03	Uranium-236	23 000 000 y	24 000
U-238	4.5E+09	2.4E+04	Uranium-238	4 500 000 000 y	24 000
Zr-93	1.5E+06	3.8E+02	Zirconium-93	1 500 000 y	380
TOTALS					
Long half-lives only (> 1 y)		8.7E+09	Long-lived only (> 1 y half-life)		8 700 000 000
Including short half-lives		1.6E+10	Including all radionuclides		16 000 000 000

According to this OPG document (see the last 2 lines), in each cubic metre there are over eight BILLION radioactive disintegrations taking place every second if we consider only the long-lived radioactive contaminants. Each disintegration releases an alpha ray, a beta ray, or a gamma ray; so there are more than eight billion of these rays emitted every second. That's more than 31 trillion rays per hour – over 274 quadrillion (274 000 000 000 000 000) rays per year!

There are five plutonium isotopes found in the steam generators. In each cubic metre there are about 39 million alpha rays given off each second from four of these five plutonium isotopes. One thousand years in the future, if the steam generators were just stored on-site as radioactive waste for that entire period, these plutonium isotopes would still be giving off about 27 million alpha particles per second, per cubic metre. Sixteen steam generators have a combined volume of about 1000 cubic metres, so all the numbers above are in fact 1000 times bigger.

Gordon Edwards, Ph.D.

[NWMO = Nuclear Waste Management Organization; OPG = Ontario Power Generation]